



Spectrum Analysis and Fourier Series or where did all those frequencies come from?

Phil Anderson

Ramapo College of New Jersey

Mahwah, NJ

Purpose:

To demonstrate FFT capable instrumentation and its use in studying periodic signals.

Equipment:


- Agilent 6000 Series Oscilloscopes with FFT measurement module, or an equivalent spectrum analyzer.
- Optional: 33220A Function / Arbitrary Waveform Generator or equivalent.

Supplementary Readings:

The Benchtop Electronics Reference Manual, by V. Veley, TAB Books, 2nd ed., 1990 HP 54600A and HP 54601A Oscilloscopes, Hewlett-Packard, 1991, Publication # 54600-90901,

HP 54657A, and HP 54658A Measurement/Storage Modules, HP, 1992, Publication # 54657-90904

Theory:



Any single-valued, finite and continuous function V(t), as shown in figure 1, having a period of $2\pi/\Box$, may be expressed as Fourier's Theorem.

 $V(t) = a0 + a1 \sin(\omega t + \theta 1) + a2 \sin(2\omega t + \theta 2) + a3\sin(3\omega t + \theta 3) + ...$ Fourier's Theorem:

where: $w = 2\pi$ radians; and t = time in seconds

But, $A \sin(\omega t + \theta) = A \sin(\omega t)\cos(\theta) + A \cos(\omega t)\sin(\theta) = a\cos(\omega t) + b\sin(\omega t)$

where: $a = A \sin(\theta)$; and $b = A \cos(\theta)$

Therefore, $V(t) = a0 + a1 \cos(\omega t) + a2\cos(2\omega t) + a3\cos(3\omega t) + ...$ + b1 $\sin(\omega t)$ + b2 $\sin(\omega t)$ + b3 $\sin(\omega t)$ +...

This means that the waveform is composed of an average value (a₀) together with fundamental sine and cosine waves and their harmonics. For the square wave above we need to determine the coefficients a₀, a₁, a₂..., b₁, b₂, b₃.... This is done by using calculus, which is outlined in Derivation below. Equation 1 is the result.



Educator's Corner Experiments

Equation 1:
$$V(t) = \frac{V_0}{2} + \frac{2V_0}{\pi} \left[\sin(\omega t) + \frac{1}{3} \sin(3\omega t) + \frac{1}{5} \sin(5\omega t) + ... + \frac{1}{n} \sin(n\omega t) + ... \right]$$

The coefficient a₀ is the average voltage, and all the other "a" coefficients are zero (no cosine terms) due to the wave's asymmetry around the vertical axis. Table 1 gives the computed value of the first five non-zero coefficients.

Table 1	a_0	b ₁	b ₃	b_5	b ₇	b ₉
Theoretical coefficients	$0.5V_{0}$	$0.637V_{0}$	$0.212V_{0}$	$0.127V_{0}$	$0.091V_{0}$	$0.091V_{0}$

Figure 2a shows the fundamental (A) and the third harmonic (B). The composite of these two frequencies (C) starts to approximate the original square wave of figure 1. Figure 2b shows the fifth harmonic (D) and the composite (E) of the fundamental, third, and the fifth harmonic. Finally, figure 2c adds the seventh harmonic (F). The composite (G) of the fundamental, third, fifth, and seventh harmonics makes a closer approximation to the original square wave of figure 1. More harmonics are needed to improve the fit. A symmetrical square wave such as this contains a large number of strong harmonics.




Figure 2a Figure 2b Figure 2c

Experimental Procedure:


- 1. Connect input 1 of the oscilloscope to the Oscilloscope's probe adjustment signal on the front panel (0 to 5V, 1.2 kHz squarewave) or connect to the function generator with the output similarly adjusted.
- 2. Press <u>Autoscale</u>. Press channel button <u>1</u>, set softkey <u>Coupling</u> to DC, and set <u>Probe</u> softkey to proper setting (if no probe, set to 1). Press <u>Time</u>, then softkey <u>Freq</u>, and record in Table 2 frequency (f) of square wave. Compute and record the other harmonic frequencies (i.e., 3f, etc.). Press <u>Voltage</u>, press softkeys <u>Vp-p</u> and <u>Vavq</u>. Record Vp-p as amplitude V₀ and the average voltage in Table 2. Using V₀ and Table 1, fill in the theoretical values for the coefficients in Table 2.

Table 2 V ₀ =					
V _{avg} =		f	3f	5f	7 f
Harmonic frequencies					
Measured frequencies					
% difference					
	a 0	b_1	b_3	b ₅	b ₇
Theoretical coefficients					
Harmonic amplitude (dB)					
Experimental coefficient					
% difference					



Educator's Corner Experiments

www.agilent.com/find/edu



- 4. Set the oscilloscope to the FFT mode: press button +/-; set Function 2 to On; press the softkey Menu; set Operand to 1; set Operation to FFT; set Units/div to 10 dB; set Ref LevI to 20 dB; press softkey FFT Menu; set Freq Span to 12 kHz; push softkey Move 0 Hz to Left; and set Window to Hanning (use Hanning to measure frequencies of peaks). Observe the unique amplitude versus frequency display. Print, photograph, or sketch the display.
- 5. Measure the frequencies of the harmonic peaks: press <u>Cursor</u>; press <u>Active Cursor</u>, set <u>f1</u> to On; use the knob below Cursor to align the movable dashed line to the first peak; record f1(F2) as the frequency (f) in Table 2; move the line to the next peak and record its frequency (3f); and measure the next three peaks and record.
- 6. Measure the amplitudes of the harmonic peaks: press softkey <u>FFT Menu</u>; set <u>Window</u> to FlatTop (use FlatTop to measure amplitudes of peaks); press <u>Cursor</u>; press softkey <u>Active Cursor</u>, set <u>f1</u> to On; move the vertical dashed line to the the fundamental peak; press <u>Move f1 to Center</u>; press softkey <u>Active Cursor</u>, set <u>V1</u> to On; move the horizontal dashed line to the 0 Hz peak; record V1(F2) as the amplitude in dB; move the horizontal line to each peak and record the amplitude in Table 2. Repeat for the next five peaks.
- 7. Since the displayed amplitudes are $dB = 20 \log(V_{rms}/1v)$, compute the amplitudes from:

 $V_{\text{peak}} = [\text{antilog}(dB/20)] / (0.707)$. Record in Table 2.

- 8. Compare theoretical and experimental values for frequencies and coefficients and record % differences.
- 9. Optional: Repeat the above procedure for a sawtooth wave. Determine the experimental coefficients and harmonic frequencies. Different harmonics may be at work.

Questions:

- 1. What would be the value of a₀ if the wave of figure 1 varied from $-V_0$ to $+V_0$ instead of 0 to V_0 ?
- 2. What is the value of the voltage of the wave of figure 1 when t =1 second?
- 3. Derive the coefficients for a sawtooth wave.



Agilent Technologies

Educator's Corner Experiments

Derivation:

$$a_{o} = \frac{1}{2\pi} \int_{0}^{2\pi} V(t)d(\omega t) = \frac{1}{2\pi} \left[V_{o} - O \right] = \frac{V_{o}}{2}$$

$$a_{\rm n} = \frac{1}{\pi} \int_{0}^{2n} V(t) \cos(n\omega t) \, d(\omega t) = \frac{1}{\pi} \left[\frac{-V_{\rm O} \sin(n\omega t)}{n} \right]_{0}^{n} = 0$$

$$b_{\rm n} = \frac{1}{\pi} \int_{0}^{2n} V(t) \sin(n\omega t) \, d(\omega t) = \frac{1}{\pi} \left[\frac{-V_{\rm O} \cos(n\omega t)}{n} \right]_{0}^{n} = \frac{V_{\rm O}}{n\pi} \left[1 - \cos(n\pi) \right]$$

when n = odd, then 1 - cos(nwt) = 0; when n = even, then 1 - cos(nwt) = 2

Therefore,
$$V(t) = \frac{V_0}{2} + \frac{2V_0}{\pi} \left[\sin(\omega t) + \frac{1}{3} \sin(3\omega t) + \frac{1}{5} \sin(5\omega t) + \dots + \frac{1}{n} \sin(n\omega t) + \dots \right]$$

These experiments have been submitted by third parties and Agilent has not tested any of the experiments. You will undertake any of the experiments solely at your own risk. Agilent is providing these experiments solely as an informational facility and without review.

AGILENT MAKES NO WARRANTY OF ANY KIND WITH REGARD TO ANY EXPERIMENT. AGILENT SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, GENERAL, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE USE OF ANY OF THE EXPERIMENTS.

射频和天线设计培训课程推荐

易迪拓培训(www.edatop.com)由数名来自于研发第一线的资深工程师发起成立,致力并专注于微波、射频、天线设计研发人才的培养;我们于2006年整合合并微波EDA网(www.mweda.com),现已发展成为国内最大的微波射频和天线设计人才培养基地,成功推出多套微波射频以及天线设计经典培训课程和ADS、HFSS等专业软件使用培训课程,广受客户好评;并先后与人民邮电出版社、电子工业出版社合作出版了多本专业图书,帮助数万名工程师提升了专业技术能力。客户遍布中兴通讯、研通高频、埃威航电、国人通信等多家国内知名公司,以及台湾工业技术研究院、永业科技、全一电子等多家台湾地区企业。

易迪拓培训课程列表: http://www.edatop.com/peixun/rfe/129.html



射频工程师养成培训课程套装

该套装精选了射频专业基础培训课程、射频仿真设计培训课程和射频电路测量培训课程三个类别共 30 门视频培训课程和 3 本图书教材;旨在引领学员全面学习一个射频工程师需要熟悉、理解和掌握的专业知识和研发设计能力。通过套装的学习,能够让学员完全达到和胜任一个合格的射频工程师的要求…

课程网址: http://www.edatop.com/peixun/rfe/110.html

ADS 学习培训课程套装

该套装是迄今国内最全面、最权威的 ADS 培训教程, 共包含 10 门 ADS 学习培训课程。课程是由具有多年 ADS 使用经验的微波射频与通信系统设计领域资深专家讲解,并多结合设计实例,由浅入深、详细而又全面地讲解了 ADS 在微波射频电路设计、通信系统设计和电磁仿真设计方面的内容。能让您在最短的时间内学会使用 ADS, 迅速提升个人技术能力,把 ADS 真正应用到实际研发工作中去,成为 ADS 设计专家...



课程网址: http://www.edatop.com/peixun/ads/13.html



HFSS 学习培训课程套装

该套课程套装包含了本站全部 HFSS 培训课程,是迄今国内最全面、最专业的 HFSS 培训教程套装,可以帮助您从零开始,全面深入学习 HFSS 的各项功能和在多个方面的工程应用。购买套装,更可超值赠送 3 个月免费学习答疑,随时解答您学习过程中遇到的棘手问题,让您的 HFSS 学习更加轻松顺畅…

课程网址: http://www.edatop.com/peixun/hfss/11.html

CST 学习培训课程套装

该培训套装由易迪拓培训联合微波 EDA 网共同推出,是最全面、系统、 专业的 CST 微波工作室培训课程套装, 所有课程都由经验丰富的专家授 课,视频教学,可以帮助您从零开始,全面系统地学习 CST 微波工作的 各项功能及其在微波射频、天线设计等领域的设计应用。且购买该套装, 还可超值赠送3个月免费学习答疑…







HFSS 天线设计培训课程套装

套装包含6门视频课程和1本图书,课程从基础讲起,内容由浅入深, 理论介绍和实际操作讲解相结合,全面系统的讲解了 HFSS 天线设计的 全过程。是国内最全面、最专业的 HFSS 天线设计课程,可以帮助您快 速学习掌握如何使用 HFSS 设计天线, 让天线设计不再难…

课程网址: http://www.edatop.com/peixun/hfss/122.html

13.56MHz NFC/RFID 线圈天线设计培训课程套装

套装包含 4 门视频培训课程,培训将 13.56MHz 线圈天线设计原理和仿 真设计实践相结合,全面系统地讲解了13.56MHz线圈天线的工作原理、 设计方法、设计考量以及使用 HFSS 和 CST 仿真分析线圈天线的具体 操作,同时还介绍了 13.56MHz 线圈天线匹配电路的设计和调试。通过 该套课程的学习,可以帮助您快速学习掌握 13.56MHz 线圈天线及其匹 配电路的原理、设计和调试…



详情浏览: http://www.edatop.com/peixun/antenna/116.html

我们的课程优势:

- ※ 成立于 2004年, 10 多年丰富的行业经验,
- ※ 一直致力并专注于微波射频和天线设计工程师的培养,更了解该行业对人才的要求
- ※ 经验丰富的一线资深工程师讲授,结合实际工程案例,直观、实用、易学

联系我们:

- ※ 易迪拓培训官网: http://www.edatop.com
- ※ 微波 EDA 网: http://www.mweda.com
- ※ 官方淘宝店: http://shop36920890.taobao.com

易迪拓信训 官方网址: http://www.edatop.com